IoT Practicals

Practical 6:

Aim: Capturing image and video with PiCamera and Raspberry Pi.

Hardware Requirements

- 1. Raspberry Pi
- 2. Picamera
- 3. MicroSD card with Raspberry Pi OS installed
- 4. Power supply for Raspberry Pi
- 5. Monitor, keyboard, mouse (for setup)

Software Requirements

- 1. Raspberry Pi OS installed and running
- 2. Python 3

Commands:

sudo raspi-config - # for configuring interface I2C

Interface -> enable Camera

reboot

sudo apt-get update

sudo apt-get upgrade

sudo apt install python3-picamera

Source Code For Image:

```
from picamera import PiCamera
import datetime
import os
# Create directory if not exists
image_folder = '/home/pi/images'
os.makedirs(image_folder, exist_ok=True)
camera = PiCamera()
camera.resolution = (1024, 768) # Optional: Set resolution
timestamp = datetime.datetime.now().strftime("%Y%m%d_%H%M%S")
#image_path = f"{image_folder}/image_{timestamp}.jpg"
image_path = "{}/image_{{}.jpg".format(image_folder, timestamp)
camera.start_preview() # Optional: Shows camera preview
camera.capture(image_path)
camera.stop_preview()
#print(f"Image captured and saved to {image_path}")
```

print("Image captured and saved to {}".format(image_path))

Source Code For Video:

```
from picamera import PiCamera
from time import sleep
import datetime
import os
# Create directory if not exists
video_folder = '/home/pi/videos'
os.makedirs(video_folder, exist_ok=True)
camera = PiCamera()
camera.resolution = (1024, 768) # Optional: Set resolution
timestamp = datetime.datetime.now().strftime("%Y%m%d_%H%M%S")
video_path = "{}/video_{{}}.h264".format(video_folder, timestamp) # .h264 is raw video format
camera.start_preview() # Optional: Shows camera preview
camera.start_recording(video_path)
sleep(10) # Records for 10 seconds (change as needed)
```

```
camera.stop_recording()
camera.stop_preview()

print("Video recorded and saved to {}".format(video_path))
```

Output: Stick picture of the output captured during the session.